



It is made up of two parts: a clip placed near the push handles to hold the upper end of the walking stick; and a small plastic cup with drainage holes attached to the lower leg of the walker (above the castors or rubber feet) to hold the end of the stick.

Simply place the end of the walking stick into the base cup and push the stick against the upper clip to secure. Gently pull the stick outwards to release – no latches or buttons involved.

Suitable for all BetterLiving walking frames and wheeled walkers excluding the Tri-Wheel.





Distributed by novis

DECEMBER
2016 ©